

Lexus

GS300 (JZ)

3000	GS300	Sal	03/93-08/97	156/212	A	ABS	JZS147	2JZ-GE				OJ-0216 A30, B56, C34, D48	IJ-6253 A1-, B112, C34	BT-100 A26, B96, C90	BT-99 A26, B98, C64
------	-------	-----	-------------	---------	---	-----	--------	--------	--	--	--	-------------------------------	---------------------------	-------------------------	------------------------

GX 470

4700	GX 470 32v V8 4X4 (Fr) [225] USA Model	Suv	01/03-12/06	/0	M/A				TO-8-09-322 A30, M648, A1-30, D	TO-8-09-322 A30, M648, A1-30, D	OJ-0259 A30, B70, C30, D-NR		BT-3117 A28, B125, C103	
------	---	-----	-------------	----	-----	--	--	--	------------------------------------	------------------------------------	--------------------------------	--	----------------------------	--

IS200

2000	IS200 24v RWD [33] (Rear)	Sal	04/99-on	114/155	M/A	ABS	GXE10	1G-FE				OJ-0244 A26, B56, C25, D48		BT-21 A24.5, B102, C85
------	------------------------------	-----	----------	---------	-----	-----	-------	-------	--	--	--	-------------------------------	--	---------------------------

LS (UC)

4000	LS 400 32v	Sal	12/89-12/94	180/245	A	ABS	UCF10	1UZ-FE				OJ-0216 A30, B56, C34, D48		BT-100 A26, B96, C90
4000	LS 400 32v	Sal	12/94-08/97	194/264	A	ABS	UCF20	1UZ-FE				OJ-0216 A30, B56, C34, D48		BT-100 A26, B96, C90

LX 470

4700	LX 470 32v V8 4X4 (Fr) [225] USA Model	Suv	01/98-12/06	175/0	A	ABS		2UZ-FE	TO-8-09-321 A30, M708, A1-30, D	TO-8-09-321 A30, M708, A1-30, D	OJ-0205 A30, B73, C30, D-NR		BT-194 A33, B142, C112
------	---	-----	-------------	-------	---	-----	--	--------	------------------------------------	------------------------------------	--------------------------------	--	---------------------------

RX 300

3000	RX 300 24v VVT-I	Suv	01/99-12/03	148/0	A		MCU10W	1MZ-FE	TO-8-09-315 A30, M564, A1-112, D	TO-8-09-315 A30, M564, A1-112, D	OJ-0217 A30, B56, C27, D-NR		BT-31003 A25, B108, C90.5
3000	RX 300 24v VVT-I	Suv	01/99-12/03	148/0	A	ABS	MCU10W	1MZ-FE	TO-8-09-315A A30, M564, A1-112, D48	TO-8-09-315A A30, M564, A1-112, D48	OJ-0224 A30, B56, C27, D48		BT-31003 A25, B108, C90.5
3000	RX 300 24v VVT-I 4X4 (Rr) [166] Japanese Production	Suv	10/00-05/03	148/201	A	ABS	MCU10W	1MZ-FE			OJ-0253 A30, B59, C24, D48		BT-NR A, B, C
3000	RX 300 24v VVT-I 4X4 (Fr) [225] USA Model	Suv	10/00-05/03	148/0	A	ABS	MCU10W	1MZ-FE	TO-8-09-114A A26, M638, A1-23, D48	TO-8-09-214A A26, M993, A1-23, D48			
3000	RX 300 24v 4X4 (Fr) [34] (Front) [225] USA Model	Suv	05/03-on	150/204	A	ABS	MCU	1MZ-FE	TO-8-09-137A A30, M652, A1-24, D48		OJ-TBA A, B, C, D-NR		BT-TBA A, B, C

RX 350

3500	RX 350 24v 4X4 (Fr) [225] USA Model	Suv	02/06-on	203/276	A	ABS	MCU	2GR-FE	TO-8-09-137A A30, M652, A1-24, D48		OJ-TBA A, B, C, D-NR		BT-TBA A, B, C
------	--	-----	----------	---------	---	-----	-----	--------	---------------------------------------	--	-------------------------	--	-------------------